

FIG.1




FIG.2




FIG.3




FIG.4




FIG.5




FIG.6




FIG.7




FIG.8

The image shows a graphical user interface for an 'ELECTRONIC MAIL' application. The main window has a title bar with the text 'ELECTRONIC MAIL' and three standard window control buttons (minimize, maximize, close). Below the title bar is a menu bar with the following items: 'FILE(F)', 'VIEW(V)', 'MESSAGE(M)', and 'HELP(H)'. On the left side of the main window, there is a vertical list of three items, each preceded by a downward-pointing triangle: 'RECEIVED MAIL', 'SEND MAIL', and 'SENT MAIL'. To the right of this list is a table with two columns: 'SENDER' and 'SUBJECT'. The table has one empty row below the headers. Overlaid on the main window is a smaller dialog box titled 'INTERKEY'. This dialog box has a close button in its title bar. The text inside the dialog box reads: 'INTERKEY RECOGNIZED.', 'INPUT PERSONAL CODE.', and 'PERSONALCODE(P)'. Below the text is a text input field containing four asterisks '****'. At the bottom of the dialog box are two buttons: 'O K' and 'CANCEL'.

| ELECTRONIC MAIL | | |
|------------------------------------|--------|---------|
| FILE(F) VIEW(V) MESSAGE(M) HELP(H) | | |
| ▼ RECEIVED MAIL | SENDER | SUBJECT |
| ▼ SEND MAIL | | |
| ▼ SENT MAIL | | |

INTERKEY

INTERKEY RECOGNIZED.
INPUT PERSONAL CODE.
PERSONALCODE(P)

FIG.9




FIG.10

The image shows a graphical user interface for an 'ELECTRONIC MAIL' application. The main window has a title bar with the text 'ELECTRONIC MAIL' and three standard window control buttons (minimize, maximize, close). Below the title bar is a menu bar with the following items: 'FILE(F)', 'VIEW(V)', 'MESSAGE(M)', and 'HELP(H)'. On the left side of the main window, there is a vertical list of mail folders: 'RECEIVED MAIL', 'SEND MAIL', and 'SENT MAIL', each preceded by a downward-pointing triangle icon. To the right of this list is a table with two columns: 'SENDER' and 'SUBJECT'. An 'INTERKEY' dialog box is open in the foreground, partially obscuring the main window. The dialog box has a title bar with the text 'INTERKEY' and a close button. Below the title bar, the dialog box is titled 'READING SETTINGS'. It contains a list of settings: '✓ NETWORK CONNECTION INFORMATION', 'PERSONAL COMMUNICATIONS INFORMATION', 'PERSONAL ENVIRONMENT INFORMATION', and 'INFORMATION'. At the bottom right of the dialog box is a 'CANCEL' button.

ELECTRONIC MAIL

FILE(F) VIEW(V) MESSAGE(M) HELP(H)

▼ RECEIVED MAIL

▼ SEND MAIL

▼ SENT MAIL

| SENDER | SUBJECT |
|--------|---------|
|--------|---------|

INTERKEY

READING SETTINGS

✓ NETWORK CONNECTION INFORMATION

PERSONAL COMMUNICATIONS INFORMATION

PERSONAL ENVIRONMENT INFORMATION

INFORMATION

CANCEL

FIG.11




FIG.12




FIG.13




FIG.14




FIG.15




FIG.16




FIG.17




FIG.18

INTERKEY DATA INPUT

NETWORK CONNECTION
INFORMATION

ACCESS POINT

03

12345678

ACCESS USERNAME

t-yamada

ACCESS PASSWORD

TCP/IP SETTINGS

255. 255. 255. 255

255. 255. 255. 254

BACK(B)

NEXT(N)

CANCEL

FIG.19


| INTERKEY DATA INPUT | |  |
|--|---|---|
| PERSONAL COMMUNICATIONS INFORMATION | | |
| SENDER | <input type="text" value="YAMADA TARO"/> | |
| MAIL ADDRESS | <input type="text" value="samp@panther.ne.jp"/> | |
| MAIL USERNAME | <input type="text" value="taro yamada"/> | |
| MAIL PASSWORD | <input type="text" value="*****"/> | |
| RECEIVE MAIL SERVER SETTING | <input type="text" value="pop.panther.ne.jp"/> | |
| SEND MAIL SERVER SETTING | <input type="text" value="smtp.panther."/> | |
| PROXY SERVER SETTING | <input type="text"/> | |
| <input type="checkbox"/> PASSWORD AUTHORIZATION (SPA)REQUIRED | | |
| <div><input type="button" value="BACK(B)"/> <input type="button" value="NEXT(N)"/> <input type="button" value="CANCEL"/></div> | | |

FIG.20

INTERKEY DATA INPUT

PERSONAL ENVIRONMENT INFORMATION

☒ BROWSER CUSTOMIZATION DATA

☒ MAIL SOFTWARE CUSTOMIZATION DATA

☐ OS CUSTOMIZATION DATA

SELECT FEP TYPE

STANDARD FEP ▼

BACK (B) NEXT (N) CANCEL

FIG.21

INTERKEY DATA INPUT

NETWORK
CONNECTION
INFORMATION

PERSONAL
COMMUNICATIONS
INFORMATION

PERSONAL
ENVIRONMENT
INFORMATION

SENDER

YAMADA TARO

MAIL ADDRESS

samp@panther.ne.jp

MAIL USERNAME

taro yamada

MAIL PASSWORD

RECEIVE MAIL
SERVER SETTING

pop.panther.ne.jp

SEND MAIL
SERVER SETTING

smtp.panther.ne.jp

BACK(B)

FINISH(N)

CANCEL